

## Kratki vodič za upotrebu NEXI Akumulatorska vezačica sa plug-in baterijom




**HR** - Da biste preuzeli cjelovit priručnik s uputama, idite na web stranicu [www.campagnola.it](http://www.campagnola.it) ili skenirajte QR kod. Ovaj brzi vodič ne zamjenjuje priručnik proizvoda koji se u svakom slučaju mora pročitati i razumjeti u cijelosti.



## POČETAK

1



Prije prve upotrebe u potpunosti napunite baterije.

3



Uključite vezačicu.  
Nakon zvučnog signala  
upalit će se zaslon.

2




Umetnite  
bateriju.

4



Za vezivanje pritisnite  
okidač.


## ZASLON



Nivo napunjenosti baterije (%).

Broj vezivanja od trenutka pokretanja vezačice.





## NAČINI VEZIVANJA




• Pritisnite dugme.

- L1= 3 okretaja
- L2= 4 okretaja
- L3= 5 okretaja
- L4= 6 okretaja
- L5= 7 okretaja
- L6= 8 okretaja

## ZAMJENA VEZICE NA KOLUTU




7



Ponovno montirajte poklopac koluta okretanjem u smjeru suprotnom od kazaljke na satu.


Prerežite vezice koje su ostale izvan koluta.



Provjerite da li je vezica postavljena u pravom smjeru, te da li je slučajno zapetljana ili ima čvorove.

8

Umetnite vezicu u pogonski valjak.



9


Umetnite bateriju.



10

Pritisnite dugme.

Povucite okidač.



Uklonite testnu traku pincetom.

## ČIŠĆENJE I ODRŽAVANJE

1



2



3



4



5



6

